

Oriental Motor Short Lead Time Products

No.	Product Code	Product Category	Product Series	Product Type
1	AZM24AK	αSTEP	αSTEP AZ Series	MOTOR
2	AZM26AK	αSTEP	αSTEP AZ Series	MOTOR
3	AZM46AC	αSTEP	αSTEP AZ Series	MOTOR
4	AZM46AK	αSTEP	αSTEP AZ Series	MOTOR
5	AZM66AC	αSTEP	αSTEP AZ Series	MOTOR
6	AZM66AK	αSTEP	αSTEP AZ Series	MOTOR
7	AZM69AC	αSTEP	αSTEP AZ Series	MOTOR
8	AZM69AK	αSTEP	αSTEP AZ Series	MOTOR
9	AZD-C	αSTEP	αSTEP AZ Series	MOTOR
10	AZD-CD	αSTEP	αSTEP AZ Series	MOTOR
11	AZD-K	αSTEP	αSTEP AZ Series	MOTOR
12	AZD-KD	αSTEP	αSTEP AZ Series	MOTOR
13	AZD-CX	αSTEP	αSTEP AZ Series	MOTOR
14	AZD-KX	αSTEP	αSTEP AZ Series	MOTOR
15	AZD-CED	αSTEP	αSTEP AZ Series	MOTOR

16	<u>AZD-KED2</u>	α STEP	α STEP AZ Series	MOTOR
17	<u>AZD-KEP2</u>	α STEP	α STEP AZ Series	MOTOR
18	<u>AZD-CEP</u>	α STEP	α STEP AZ Series	MOTOR
19	<u>AZD2A-KS3</u>	α STEP	α STEP AZ Series	MOTOR
20	<u>AZD3A-KS3</u>	α STEP	α STEP AZ Series	MOTOR
21	<u>AZD4A-KS3</u>	α STEP	α STEP AZ Series	MOTOR
22	<u>AZD2A-KM3</u>	α STEP	α STEP AZ Series	MOTOR
23	<u>AZD3A-KM3</u>	α STEP	α STEP AZ Series	MOTOR
24	<u>AZD4A-KM3</u>	α STEP	α STEP AZ Series	MOTOR
25	<u>AZD2A-KED</u>	α STEP	α STEP AZ Series	MOTOR
26	<u>AZD3A-KED</u>	α STEP	α STEP AZ Series	MOTOR
27	<u>AZD4A-KED</u>	α STEP	α STEP AZ Series	MOTOR
28	<u>CC020VZ2F2</u>	α STEP	α STEP AZ Series	MOTOR
29	<u>CC030VZ2F2</u>	α STEP	α STEP AZ Series	MOTOR
30	<u>CC050VZ2F2</u>	α STEP	α STEP AZ Series	MOTOR
31	<u>CC050VZ2R2</u>	α STEP	α STEP AZ Series	MOTOR
32	<u>CC030VZFA</u>	α STEP	α STEP AZ Series	MOTOR

33	<u>CC005VZF2-M</u>	α STEP	α STEP AZ Series	MOTOR
34	<u>CC010VZF2-M</u>	α STEP	α STEP AZ Series	MOTOR
35	<u>CC020VZF2-M</u>	α STEP	α STEP AZ Series	MOTOR
36	<u>CC030VZF2-M</u>	α STEP	α STEP AZ Series	MOTOR
37	<u>CC050VZF2-M</u>	α STEP	α STEP AZ Series	MOTOR
38	<u>CC040VZF2-M</u>	α STEP	α STEP AZ Series	MOTOR
39	<u>CC070VZF2-M</u>	α STEP	α STEP AZ Series	MOTOR
40	<u>CC100VZF2-M</u>	α STEP	α STEP AZ Series	MOTOR
41	<u>CC150VZF2-M</u>	α STEP	α STEP AZ Series	MOTOR
42	<u>CC030VZR2-M</u>	α STEP	α STEP AZ Series	MOTOR
43	<u>CC020VZR2-M</u>	α STEP	α STEP AZ Series	MOTOR
44	<u>CC050VZR2-M</u>	α STEP	α STEP AZ Series	MOTOR
45	<u>CC005VZF-M</u>	α STEP	α STEP AZ Series	MOTOR
46	<u>CC010VZF-M</u>	α STEP	α STEP AZ Series	MOTOR
47	<u>CC020VZF-M</u>	α STEP	α STEP AZ Series	MOTOR
48	<u>CC030VZF-M</u>	α STEP	α STEP AZ Series	MOTOR
49	<u>CC040VZF-M</u>	α STEP	α STEP AZ Series	MOTOR

50	<u>CC050VZF-M</u>	α STEP	α STEP AZ Series	MOTOR
51	<u>CC070VZF-M</u>	α STEP	α STEP AZ Series	MOTOR
52	<u>CC100VZF-M</u>	α STEP	α STEP AZ Series	MOTOR
53	<u>CC150VZF-M</u>	α STEP	α STEP AZ Series	MOTOR
54	<u>CC030VZR-M</u>	α STEP	α STEP AZ Series	MOTOR
55	<u>CC050VZR-M</u>	α STEP	α STEP AZ Series	MOTOR
56	<u>CC070VZR-M</u>	α STEP	α STEP AZ Series	MOTOR
57	<u>CC100VZR-M</u>	α STEP	α STEP AZ Series	MOTOR
58	<u>CC050VZF-B</u>	α STEP	α STEP AZ Series	MOTOR
59	<u>CC030VZF-B</u>	α STEP	α STEP AZ Series	MOTOR
60	<u>CC050VZR-B</u>	α STEP	α STEP AZ Series	MOTOR
61	<u>CC070VZR-B</u>	α STEP	α STEP AZ Series	MOTOR
62	<u>CC100VZR-B</u>	α STEP	α STEP AZ Series	MOTOR
63	<u>CC020V3F-B</u>	α STEP	α STEP AZ Series	MOTOR
64	<u>CC030V3F-B</u>	α STEP	α STEP AZ Series	MOTOR
65	<u>CC050V3F-B</u>	α STEP	α STEP AZ Series	MOTOR
66	<u>CC030V3R-B</u>	α STEP	α STEP AZ Series	MOTOR

67	<u>CC050V3R-B</u>	α STEP	α STEP AZ Series	MOTOR
68	<u>CC005VNF-E2</u>	α STEP	α STEP AZ Series	MOTOR
69	<u>CC010VNF-E2</u>	α STEP	α STEP AZ Series	MOTOR
70	<u>CC020VNF-E2</u>	α STEP	α STEP AZ Series	MOTOR
71	<u>CC030VNF-E2</u>	α STEP	α STEP AZ Series	MOTOR
72	<u>CC040VNF-E2</u>	α STEP	α STEP AZ Series	MOTOR
73	<u>CC050VNF-E2</u>	α STEP	α STEP AZ Series	MOTOR
74	<u>CC020VNR-E2</u>	α STEP	α STEP AZ Series	MOTOR
75	<u>CC030VNR-E2</u>	α STEP	α STEP AZ Series	MOTOR
76	<u>CC050VNR-E2</u>	α STEP	α STEP AZ Series	MOTOR
77	<u>CC070VZF-E</u>	α STEP	α STEP AZ Series	MOTOR
78	<u>CC100VZF-E</u>	α STEP	α STEP AZ Series	MOTOR
79	<u>CC150VZF-E</u>	α STEP	α STEP AZ Series	MOTOR
80	<u>CC070VZR-E</u>	α STEP	α STEP AZ Series	MOTOR
81	<u>CC100VZR-E</u>	α STEP	α STEP AZ Series	MOTOR
82	<u>LC03D06A</u>	α STEP	α STEP AZ Series	MOTOR
83	<u>NETC02-CC</u>	α STEP	α STEP AZ Series	MOTOR

84	<u>CC001-RS4</u>	α STEP	α STEP AZ Series	MOTOR
85	<u>CC05IF-USB</u>	α STEP	α STEP AZ Series	MOTOR
86	<u>PKP243D23A2</u>	α STEP	α STEP AZ Series	MOTOR
87	<u>PKP244D23A2</u>	α STEP	α STEP AZ Series	MOTOR
88	<u>PKP245D23A2</u>	α STEP	α STEP AZ Series	MOTOR
89	<u>PKP246D23A2</u>	α STEP	α STEP AZ Series	MOTOR
90	<u>PKP546N18A2</u>	α STEP	α STEP AZ Series	MOTOR
91	<u>PKP266D28A2</u>	α STEP	α STEP AZ Series	MOTOR
92	<u>PKP268D28A2</u>	α STEP	α STEP AZ Series	MOTOR
93	<u>PKP566FN24A2</u>	α STEP	α STEP AZ Series	MOTOR
94	<u>PKP569FN24A2</u>	α STEP	α STEP AZ Series	MOTOR
95	<u>CVD205B-K</u>	α STEP	α STEP AZ Series	MOTOR
96	<u>CVD215B-K</u>	α STEP	α STEP AZ Series	MOTOR
97	<u>CVD223B-K</u>	α STEP	α STEP AZ Series	MOTOR
98	<u>CVD228B-K</u>	α STEP	α STEP AZ Series	MOTOR
99	<u>CVD206B-K</u>	α STEP	α STEP AZ Series	MOTOR
100	<u>CVD242B-K</u>	α STEP	α STEP AZ Series	MOTOR

101	<u>CVD245B-K</u>	α STEP	α STEP AZ Series	MOTOR
102	<u>CVD223FB-K</u>	α STEP	α STEP AZ Series	MOTOR
103	<u>CVD205BR-K</u>	α STEP	α STEP AZ Series	MOTOR
104	<u>CVD215BR-K</u>	α STEP	α STEP AZ Series	MOTOR
105	<u>CVD223BR-K</u>	α STEP	α STEP AZ Series	MOTOR
106	<u>CVD228BR-K</u>	α STEP	α STEP AZ Series	MOTOR
107	<u>CVD206BR-K</u>	α STEP	α STEP AZ Series	MOTOR
108	<u>CVD242BR-K</u>	α STEP	α STEP AZ Series	MOTOR
109	<u>CVD245BR-K</u>	α STEP	α STEP AZ Series	MOTOR
110	<u>CVD223FBR-K</u>	α STEP	α STEP AZ Series	MOTOR
111	<u>CVD223F-K</u>	α STEP	α STEP AZ Series	MOTOR
112	<u>CVD205-K</u>	α STEP	α STEP AZ Series	MOTOR
113	<u>CVD206-K</u>	α STEP	α STEP AZ Series	MOTOR
114	<u>CVD215-K</u>	α STEP	α STEP AZ Series	MOTOR
115	<u>CVD223-K</u>	α STEP	α STEP AZ Series	MOTOR
116	<u>CVD228-K</u>	α STEP	α STEP AZ Series	MOTOR
117	<u>CVD512B-K</u>	α STEP	α STEP AZ Series	MOTOR

118	<u>CVD518B-K</u>	α STEP	α STEP AZ Series	MOTOR
119	<u>CVD524B-K</u>	α STEP	α STEP AZ Series	MOTOR
120	<u>CVD503B-K</u>	α STEP	α STEP AZ Series	MOTOR
121	<u>CVD507B-K</u>	α STEP	α STEP AZ Series	MOTOR
122	<u>CVD514B-K</u>	α STEP	α STEP AZ Series	MOTOR
123	<u>CVD528B-K</u>	α STEP	α STEP AZ Series	MOTOR
124	<u>CVD538B-K</u>	α STEP	α STEP AZ Series	MOTOR
125	<u>CVD512BR-K</u>	α STEP	α STEP AZ Series	MOTOR
126	<u>CVD518BR-K</u>	α STEP	α STEP AZ Series	MOTOR
127	<u>CVD524BR-K</u>	α STEP	α STEP AZ Series	MOTOR
128	<u>CVD503BR-K</u>	α STEP	α STEP AZ Series	MOTOR
129	<u>CVD507BR-K</u>	α STEP	α STEP AZ Series	MOTOR
130	<u>CVD514BR-K</u>	α STEP	α STEP AZ Series	MOTOR
131	<u>CVD528BR-K</u>	α STEP	α STEP AZ Series	MOTOR
132	<u>CVD538BR-K</u>	α STEP	α STEP AZ Series	MOTOR
133	<u>CVD503-K</u>	α STEP	α STEP AZ Series	MOTOR
134	<u>CVD507-K</u>	α STEP	α STEP AZ Series	MOTOR

135	<u>CVD512-K</u>	α STEP	α STEP AZ Series	MOTOR
136	<u>CVD514-K</u>	α STEP	α STEP AZ Series	MOTOR
137	<u>CVD518-K</u>	α STEP	α STEP AZ Series	MOTOR
138	<u>CVD524-K</u>	α STEP	α STEP AZ Series	MOTOR
139	<u>CVD4A-KED</u>	α STEP	α STEP AZ Series	MOTOR
140	<u>LC2B06A</u>	α STEP	α STEP AZ Series	MOTOR
141	<u>LC2B06B</u>	α STEP	α STEP AZ Series	MOTOR
142	<u>LC2B06C</u>	α STEP	α STEP AZ Series	MOTOR
143	<u>LC2B06E</u>	α STEP	α STEP AZ Series	MOTOR
144	<u>LCS01CVK2</u>	α STEP	α STEP AZ Series	MOTOR
145	<u>LCD06CA-2M</u>	α STEP	α STEP AZ Series	MOTOR
146	<u>LC2B10E</u>	α STEP	α STEP AZ Series	MOTOR
147	<u>CCM030V2AEF</u>	α STEP	α STEP AZ Series	MOTOR
148	<u>LC5N06A</u>	α STEP	α STEP AZ Series	MOTOR
149	<u>LC5N06E</u>	α STEP	α STEP AZ Series	MOTOR
150	<u>LCS04SD5</u>	α STEP	α STEP AZ Series	MOTOR
151	<u>LCD06CA-5M</u>	α STEP	α STEP AZ Series	MOTOR

152	<u>LCE08A-006</u>	α STEP	α STEP AZ Series	MOTOR
153	<u>LC02D06C</u>	α STEP	α STEP AZ Series	MOTOR
154	<u>LC02D06D</u>	α STEP	α STEP AZ Series	MOTOR
155	<u>LCD06CA-S</u>	α STEP	α STEP AZ Series	MOTOR
156	<u>DGM130R-AZAC</u>	α STEP	α STEP AZ Series	MOTOR
157	<u>DGM200R-AZAC</u>	α STEP	α STEP AZ Series	MOTOR
158	<u>DGM85R-AZAC</u>	α STEP	α STEP AZ Series	MOTOR
159	<u>DGM60-AZAK</u>	α STEP	α STEP AZ Series	MOTOR
160	<u>DGM85R-AZAK</u>	α STEP	α STEP AZ Series	MOTOR
161	<u>DGM130R-AZAK</u>	α STEP	α STEP AZ Series	MOTOR
162	<u>AZD-C</u>	α STEP	α STEP AZ Series	MOTOR
163	<u>AZD-CD</u>	α STEP	α STEP AZ Series	MOTOR
164	<u>AZD-K</u>	α STEP	α STEP AZ Series	MOTOR
165	<u>AZD-KD</u>	α STEP	α STEP AZ Series	MOTOR
166	<u>AZD-CX</u>	α STEP	α STEP AZ Series	MOTOR
167	<u>AZD-KX</u>	α STEP	α STEP AZ Series	MOTOR
168	<u>AZD-CED</u>	α STEP	α STEP AZ Series	MOTOR

169	<u>AZD-KED</u>	α STEP	α STEP AZ Series	MOTOR
170	<u>AZD-KEP</u>	α STEP	α STEP AZ Series	MOTOR
171	<u>AZD-CEP</u>	α STEP	α STEP AZ Series	MOTOR
172	<u>CC030VZF</u>	α STEP	α STEP AZ Series	MOTOR
173	<u>CC050VZF</u>	α STEP	α STEP AZ Series	MOTOR
174	<u>CC070VZF</u>	α STEP	α STEP AZ Series	MOTOR
175	<u>CC100VZF</u>	α STEP	α STEP AZ Series	MOTOR
176	<u>CC030VZR</u>	α STEP	α STEP AZ Series	MOTOR
177	<u>CC050VZR</u>	α STEP	α STEP AZ Series	MOTOR
178	<u>CC070VZR</u>	α STEP	α STEP AZ Series	MOTOR
179	<u>CC100VZR</u>	α STEP	α STEP AZ Series	MOTOR
180	<u>CC030VZF2</u>	α STEP	α STEP AZ Series	MOTOR
181	<u>CC020VZF2</u>	α STEP	α STEP AZ Series	MOTOR
182	<u>CC030VZF2</u>	α STEP	α STEP AZ Series	MOTOR
183	<u>CC050VZF2</u>	α STEP	α STEP AZ Series	MOTOR
184	<u>CC050VZR2</u>	α STEP	α STEP AZ Series	MOTOR
185	<u>BLM230HP-GFV</u>	α STEP	α STEP AZ Series	MOTOR

186	<u>BLM460SHP-GFV</u>	α STEP	α STEP AZ Series	MOTOR
187	<u>BLM5120HP-GFV</u>	α STEP	α STEP AZ Series	MOTOR
188	<u>BLM6200SHP-GFV</u>	α STEP	α STEP AZ Series	MOTOR
189	<u>GFV2G10S</u>	α STEP	α STEP AZ Series	MOTOR
190	<u>GFV2G15S</u>	α STEP	α STEP AZ Series	MOTOR
191	<u>GFV2G20S</u>	α STEP	α STEP AZ Series	MOTOR
192	<u>GFV2G30S</u>	α STEP	α STEP AZ Series	MOTOR
193	<u>GFV2G50S</u>	α STEP	α STEP AZ Series	MOTOR
194	<u>GFV2G5S</u>	α STEP	α STEP AZ Series	MOTOR
195	<u>GFV4G10S</u>	α STEP	α STEP AZ Series	MOTOR
196	<u>GFV4G15S</u>	α STEP	α STEP AZ Series	MOTOR
197	<u>GFV4G20S</u>	α STEP	α STEP AZ Series	MOTOR
198	<u>GFV4G30S</u>	α STEP	α STEP AZ Series	MOTOR
199	<u>GFV4G50S</u>	α STEP	α STEP AZ Series	MOTOR
200	<u>GFV4G5S</u>	α STEP	α STEP AZ Series	MOTOR
201	<u>GFV5G10S</u>	α STEP	α STEP AZ Series	MOTOR
202	<u>GFV5G15S</u>	α STEP	α STEP AZ Series	MOTOR

203	<u>GFV5G20S</u>	α STEP	α STEP AZ Series	MOTOR
204	<u>GFV5G30S</u>	α STEP	α STEP AZ Series	MOTOR
205	<u>GFV5G50S</u>	α STEP	α STEP AZ Series	MOTOR
206	<u>GFV5G5S</u>	α STEP	α STEP AZ Series	MOTOR
207	<u>GFV6G10S</u>	α STEP	α STEP AZ Series	MOTOR
208	<u>GFV6G15S</u>	α STEP	α STEP AZ Series	MOTOR
209	<u>GFV6G20S</u>	α STEP	α STEP AZ Series	MOTOR
210	<u>GFV6G30S</u>	α STEP	α STEP AZ Series	MOTOR
211	<u>GFV6G50S</u>	α STEP	α STEP AZ Series	MOTOR
212	<u>GFV6G5S</u>	α STEP	α STEP AZ Series	MOTOR
213	<u>BMUD60-C2</u>	α STEP	α STEP AZ Series	MOTOR
214	<u>BMUD120-C2</u>	α STEP	α STEP AZ Series	MOTOR
215	<u>BMUD30-C2</u>	α STEP	α STEP AZ Series	MOTOR
216	<u>BMUD200-C</u>	α STEP	α STEP AZ Series	MOTOR
217	<u>BMUD400-C</u>	α STEP	α STEP AZ Series	MOTOR
218	<u>BMUD400-S</u>	α STEP	α STEP AZ Series	MOTOR
219	<u>BMUD300-C</u>	α STEP	α STEP AZ Series	MOTOR

220	<u>BMUD200-A</u>	α STEP	α STEP AZ Series	MOTOR
221	<u>CC010KHBLB</u>	α STEP	α STEP AZ Series	MOTOR
222	<u>CC010KHBLF</u>	α STEP	α STEP AZ Series	MOTOR
223	<u>CC020KHBLB</u>	α STEP	α STEP AZ Series	MOTOR
224	<u>CC020KHBLF</u>	α STEP	α STEP AZ Series	MOTOR
225	<u>CC030KHBLB</u>	α STEP	α STEP AZ Series	MOTOR
226	<u>CC030KHBLF</u>	α STEP	α STEP AZ Series	MOTOR
227	<u>CC050KHBLB</u>	α STEP	α STEP AZ Series	MOTOR
228	<u>CC050KHBLF</u>	α STEP	α STEP AZ Series	MOTOR
229	<u>CC050KHBLF</u>	α STEP	α STEP AZ Series	MOTOR
230	<u>BLHM015K-A</u>	α STEP	α STEP AZ Series	MOTOR
231	<u>BLHM015K-10</u>	α STEP	α STEP AZ Series	MOTOR
232	<u>BLHM015K-20</u>	α STEP	α STEP AZ Series	MOTOR
233	<u>BLHM015K-30</u>	α STEP	α STEP AZ Series	MOTOR
234	<u>BLHM015K-5</u>	α STEP	α STEP AZ Series	MOTOR
235	<u>BLHM230K-GFS</u>	α STEP	α STEP AZ Series	MOTOR
236	<u>BLHM450K-GFS</u>	α STEP	α STEP AZ Series	MOTOR

237	<u>BLHM5100K-GFS</u>	α STEP	α STEP AZ Series	MOTOR
238	<u>GFS2G10</u>	α STEP	α STEP AZ Series	MOTOR
239	<u>GFS2G15</u>	α STEP	α STEP AZ Series	MOTOR
240	<u>GFS2G20</u>	α STEP	α STEP AZ Series	MOTOR
241	<u>GFS2G30</u>	α STEP	α STEP AZ Series	MOTOR
242	<u>GFS2G5</u>	α STEP	α STEP AZ Series	MOTOR
243	<u>GFS2G50</u>	α STEP	α STEP AZ Series	MOTOR
244	<u>GFS4G10</u>	α STEP	α STEP AZ Series	MOTOR
245	<u>GFS4G15</u>	α STEP	α STEP AZ Series	MOTOR
246	<u>GFS4G20</u>	α STEP	α STEP AZ Series	MOTOR
247	<u>GFS4G30</u>	α STEP	α STEP AZ Series	MOTOR
248	<u>GFS4G5</u>	α STEP	α STEP AZ Series	MOTOR
249	<u>GFS4G50</u>	α STEP	α STEP AZ Series	MOTOR
250	<u>GFS5G10</u>	α STEP	α STEP AZ Series	MOTOR
251	<u>GFS5G15</u>	α STEP	α STEP AZ Series	MOTOR
252	<u>GFS5G30</u>	α STEP	α STEP AZ Series	MOTOR
253	<u>GFS5G5</u>	α STEP	α STEP AZ Series	MOTOR

254	<u>GFS5G50</u>	αSTEP	αSTEP AZ Series	MOTOR
255	<u>BLHD100K</u>	αSTEP	αSTEP AZ Series	MOTOR
256	<u>BLH2D15-K</u>	αSTEP	αSTEP AZ Series	MOTOR
257	<u>BLH2D15-KD</u>	αSTEP	αSTEP AZ Series	MOTOR
258	<u>BLH2D30-K</u>	αSTEP	αSTEP AZ Series	MOTOR
259	<u>BLH2D30-KD</u>	αSTEP	αSTEP AZ Series	MOTOR
260	<u>BLH2D50-K</u>	αSTEP	αSTEP AZ Series	MOTOR
261	<u>BLH2D50-KD</u>	αSTEP	αSTEP AZ Series	MOTOR
262	<u>CC02BLH</u>	αSTEP	αSTEP AZ Series	MOTOR
263	<u>CC02AXH2</u>	αSTEP	αSTEP AZ Series	MOTOR
264	<u>CC02BLH2R</u>	αSTEP	αSTEP AZ Series	MOTOR
265	<u>CC02BLHR</u>	αSTEP	αSTEP AZ Series	MOTOR
266	<u>LHS003CC</u>	αSTEP	αSTEP AZ Series	MOTOR
267	<u>LHS003CD</u>	αSTEP	αSTEP AZ Series	MOTOR
268	<u>LHS010CC</u>	αSTEP	αSTEP AZ Series	MOTOR
269	<u>PAVR2-20K</u>	αSTEP	αSTEP AZ Series	MOTOR
270	<u>MADP02</u>	αSTEP	αSTEP AZ Series	MOTOR

271	<u>BLMR6200SK-GFV-B</u>	α STEP	α STEP AZ Series	MOTOR
272	<u>GFV6G50</u>	α STEP	α STEP AZ Series	MOTOR
273	<u>BLVD-KRD</u>	α STEP	α STEP AZ Series	MOTOR
274	<u>CCM010B1AAF</u>	α STEP	α STEP AZ Series	MOTOR
275	<u>CCM030B1AAF</u>	α STEP	α STEP AZ Series	MOTOR
276	<u>LC03D06A</u>	α STEP	α STEP AZ Series	MOTOR
277	<u>PAVR-20KZ</u>	α STEP	α STEP AZ Series	MOTOR
278	<u>2IK6GN-AW2U</u>	α STEP	α STEP AZ Series	MOTOR
279	<u>2IK6GN-CW2E</u>	α STEP	α STEP AZ Series	MOTOR
280	<u>2IK6RGN-CW2E</u>	α STEP	α STEP AZ Series	MOTOR
281	<u>2RK6GN-CW2E</u>	α STEP	α STEP AZ Series	MOTOR
282	<u>3IK15GN-AW2U</u>	α STEP	α STEP AZ Series	MOTOR
283	<u>3IK15GN-CW2E</u>	α STEP	α STEP AZ Series	MOTOR
284	<u>3IK15GN-SW2</u>	α STEP	α STEP AZ Series	MOTOR
285	<u>3IK15RGN-CW2E</u>	α STEP	α STEP AZ Series	MOTOR
286	<u>3RK15GN-CW2E</u>	α STEP	α STEP AZ Series	MOTOR
287	<u>4IK25GN-AW2U</u>	α STEP	α STEP AZ Series	MOTOR

288	<u>4IK25GN-CW2E</u>	α STEP	α STEP AZ Series	MOTOR
289	<u>4IK25GN-SW2</u>	α STEP	α STEP AZ Series	MOTOR
290	<u>4IK25RGN-CW2E</u>	α STEP	α STEP AZ Series	MOTOR
291	<u>4RK25GN-CW2E</u>	α STEP	α STEP AZ Series	MOTOR
292	<u>5IK40GN-CW2E</u>	α STEP	α STEP AZ Series	MOTOR
293	<u>5IK40GN-SW2</u>	α STEP	α STEP AZ Series	MOTOR
294	<u>5IK40RGN-CW2E</u>	α STEP	α STEP AZ Series	MOTOR
295	<u>5RK40GN-CW2E</u>	α STEP	α STEP AZ Series	MOTOR
296	<u>5IK60GE-CW2E</u>	α STEP	α STEP AZ Series	MOTOR
297	<u>5IK60GE-SW2</u>	α STEP	α STEP AZ Series	MOTOR
298	<u>5IK90GE-CW2E</u>	α STEP	α STEP AZ Series	MOTOR
299	<u>5IK90GE-SW2</u>	α STEP	α STEP AZ Series	MOTOR
300	<u>2GN10XK</u>	α STEP	α STEP AZ Series	MOTOR
301	<u>2GN3K</u>	α STEP	α STEP AZ Series	MOTOR
302	<u>2GN3.6K</u>	α STEP	α STEP AZ Series	MOTOR
303	<u>2GN5K</u>	α STEP	α STEP AZ Series	MOTOR
304	<u>2GN6K</u>	α STEP	α STEP AZ Series	MOTOR

305	<u>2GN7.5K</u>	α STEP	α STEP AZ Series	MOTOR
306	<u>2GN9K</u>	α STEP	α STEP AZ Series	MOTOR
307	<u>2GN12.5K</u>	α STEP	α STEP AZ Series	MOTOR
308	<u>2GN15K</u>	α STEP	α STEP AZ Series	MOTOR
309	<u>2GN18K</u>	α STEP	α STEP AZ Series	MOTOR
310	<u>2GN25K</u>	α STEP	α STEP AZ Series	MOTOR
311	<u>2GN30K</u>	α STEP	α STEP AZ Series	MOTOR
312	<u>2GN36K</u>	α STEP	α STEP AZ Series	MOTOR
313	<u>2GN50K</u>	α STEP	α STEP AZ Series	MOTOR
314	<u>2GN60K</u>	α STEP	α STEP AZ Series	MOTOR
315	<u>2GN75K</u>	α STEP	α STEP AZ Series	MOTOR
316	<u>2GN90K</u>	α STEP	α STEP AZ Series	MOTOR
317	<u>2GN100K</u>	α STEP	α STEP AZ Series	MOTOR
318	<u>2GN120K</u>	α STEP	α STEP AZ Series	MOTOR
319	<u>2GN150K</u>	α STEP	α STEP AZ Series	MOTOR
320	<u>2GN180K</u>	α STEP	α STEP AZ Series	MOTOR
321	<u>3GN3K</u>	α STEP	α STEP AZ Series	MOTOR

322	<u>3GN3.6K</u>	α STEP	α STEP AZ Series	MOTOR
323	<u>3GN5K</u>	α STEP	α STEP AZ Series	MOTOR
324	<u>3GN6K</u>	α STEP	α STEP AZ Series	MOTOR
325	<u>3GN7.5K</u>	α STEP	α STEP AZ Series	MOTOR
326	<u>3GN9K</u>	α STEP	α STEP AZ Series	MOTOR
327	<u>3GN12.5K</u>	α STEP	α STEP AZ Series	MOTOR
328	<u>3GN15K</u>	α STEP	α STEP AZ Series	MOTOR
329	<u>3GN18K</u>	α STEP	α STEP AZ Series	MOTOR
330	<u>3GN25K</u>	α STEP	α STEP AZ Series	MOTOR
331	<u>3GN30K</u>	α STEP	α STEP AZ Series	MOTOR
332	<u>3GN36K</u>	α STEP	α STEP AZ Series	MOTOR
333	<u>3GN50K</u>	α STEP	α STEP AZ Series	MOTOR
334	<u>3GN60K</u>	α STEP	α STEP AZ Series	MOTOR
335	<u>3GN75K</u>	α STEP	α STEP AZ Series	MOTOR
336	<u>3GN90K</u>	α STEP	α STEP AZ Series	MOTOR
337	<u>3GN100K</u>	α STEP	α STEP AZ Series	MOTOR
338	<u>3GN120K</u>	α STEP	α STEP AZ Series	MOTOR

339	<u>3GN150K</u>	α STEP	α STEP AZ Series	MOTOR
340	<u>3GN180K</u>	α STEP	α STEP AZ Series	MOTOR
341	<u>4GN10XK</u>	α STEP	α STEP AZ Series	MOTOR
342	<u>4GN3K</u>	α STEP	α STEP AZ Series	MOTOR
343	<u>4GN3.6K</u>	α STEP	α STEP AZ Series	MOTOR
344	<u>4GN5K</u>	α STEP	α STEP AZ Series	MOTOR
345	<u>4GN6K</u>	α STEP	α STEP AZ Series	MOTOR
346	<u>4GN7.5K</u>	α STEP	α STEP AZ Series	MOTOR
347	<u>4GN9K</u>	α STEP	α STEP AZ Series	MOTOR
348	<u>4GN12.5K</u>	α STEP	α STEP AZ Series	MOTOR
349	<u>4GN15K</u>	α STEP	α STEP AZ Series	MOTOR
350	<u>4GN18K</u>	α STEP	α STEP AZ Series	MOTOR
351	<u>4GN25K</u>	α STEP	α STEP AZ Series	MOTOR
352	<u>4GN30K</u>	α STEP	α STEP AZ Series	MOTOR
353	<u>4GN36K</u>	α STEP	α STEP AZ Series	MOTOR
354	<u>4GN50K</u>	α STEP	α STEP AZ Series	MOTOR
355	<u>4GN60K</u>	α STEP	α STEP AZ Series	MOTOR

356	<u>4GN75K</u>	α STEP	α STEP AZ Series	MOTOR
357	<u>4GN90K</u>	α STEP	α STEP AZ Series	MOTOR
358	<u>4GN100K</u>	α STEP	α STEP AZ Series	MOTOR
359	<u>4GN120K</u>	α STEP	α STEP AZ Series	MOTOR
360	<u>4GN150K</u>	α STEP	α STEP AZ Series	MOTOR
361	<u>4GN180K</u>	α STEP	α STEP AZ Series	MOTOR
362	<u>5GN100K</u>	α STEP	α STEP AZ Series	MOTOR
363	<u>5GN12.5K</u>	α STEP	α STEP AZ Series	MOTOR
364	<u>5GN120K</u>	α STEP	α STEP AZ Series	MOTOR
365	<u>5GN150K</u>	α STEP	α STEP AZ Series	MOTOR
366	<u>5GN15K</u>	α STEP	α STEP AZ Series	MOTOR
367	<u>5GN180K</u>	α STEP	α STEP AZ Series	MOTOR
368	<u>5GN18K</u>	α STEP	α STEP AZ Series	MOTOR
369	<u>5GN25K</u>	α STEP	α STEP AZ Series	MOTOR
370	<u>5GN3.6K</u>	α STEP	α STEP AZ Series	MOTOR
371	<u>5GN30K</u>	α STEP	α STEP AZ Series	MOTOR
372	<u>5GN36K</u>	α STEP	α STEP AZ Series	MOTOR

373	<u>5GN3K</u>	α STEP	α STEP AZ Series	MOTOR
374	<u>5GN50K</u>	α STEP	α STEP AZ Series	MOTOR
375	<u>5GN5K</u>	α STEP	α STEP AZ Series	MOTOR
376	<u>5GN60K</u>	α STEP	α STEP AZ Series	MOTOR
377	<u>5GN6K</u>	α STEP	α STEP AZ Series	MOTOR
378	<u>5GN7.5K</u>	α STEP	α STEP AZ Series	MOTOR
379	<u>5GN75K</u>	α STEP	α STEP AZ Series	MOTOR
380	<u>5GN90K</u>	α STEP	α STEP AZ Series	MOTOR
381	<u>5GN9K</u>	α STEP	α STEP AZ Series	MOTOR
382	<u>5GE10XS</u>	α STEP	α STEP AZ Series	MOTOR
383	<u>5GE3S</u>	α STEP	α STEP AZ Series	MOTOR
384	<u>5GE5S</u>	α STEP	α STEP AZ Series	MOTOR
385	<u>5GE7.5S</u>	α STEP	α STEP AZ Series	MOTOR
386	<u>5GE9S</u>	α STEP	α STEP AZ Series	MOTOR
387	<u>5GE12.5S</u>	α STEP	α STEP AZ Series	MOTOR
388	<u>5GE15S</u>	α STEP	α STEP AZ Series	MOTOR
389	<u>5GE18S</u>	α STEP	α STEP AZ Series	MOTOR

390	<u>5GE25S</u>	α STEP	α STEP AZ Series	MOTOR
391	<u>5GE30S</u>	α STEP	α STEP AZ Series	MOTOR
392	<u>5GE36S</u>	α STEP	α STEP AZ Series	MOTOR
393	<u>5GE50S</u>	α STEP	α STEP AZ Series	MOTOR
394	<u>5GE60S</u>	α STEP	α STEP AZ Series	MOTOR
395	<u>5GE100S</u>	α STEP	α STEP AZ Series	MOTOR
396	<u>5GE180S</u>	α STEP	α STEP AZ Series	MOTOR
397	<u>FPW690C2-12.5E</u>	α STEP	α STEP AZ Series	MOTOR
398	<u>T-MU1225S-51-GP</u>	α STEP	α STEP AZ Series	MOTOR
399	<u>T-MU1238A-51-GP</u>	α STEP	α STEP AZ Series	MOTOR
400	<u>MU1225S-11</u>	α STEP	α STEP AZ Series	MOTOR
401	<u>MU1225S-21</u>	α STEP	α STEP AZ Series	MOTOR
402	<u>MU1225S-41</u>	α STEP	α STEP AZ Series	MOTOR
403	<u>MU1225S-51</u>	α STEP	α STEP AZ Series	MOTOR
404	<u>MU1238A-11B</u>	α STEP	α STEP AZ Series	MOTOR
405	<u>MU1238A-21B</u>	α STEP	α STEP AZ Series	MOTOR
406	<u>MU1238A-41B</u>	α STEP	α STEP AZ Series	MOTOR

407	<u>MU1238A-51B</u>	α STEP	α STEP AZ Series	MOTOR
408	<u>MU1428S-51</u>	α STEP	α STEP AZ Series	MOTOR
409	<u>MU825S-13</u>	α STEP	α STEP AZ Series	MOTOR
410	<u>MU825S-43</u>	α STEP	α STEP AZ Series	MOTOR
411	<u>MU825S-53</u>	α STEP	α STEP AZ Series	MOTOR
412	<u>MU925S-11</u>	α STEP	α STEP AZ Series	MOTOR
413	<u>MU925S-41</u>	α STEP	α STEP AZ Series	MOTOR
414	<u>MU925S-51</u>	α STEP	α STEP AZ Series	MOTOR
415	<u>MRS16-DUL</u>	α STEP	α STEP AZ Series	MOTOR
416	<u>MRS18-DUL</u>	α STEP	α STEP AZ Series	MOTOR
417	<u>MDE1225-24L</u>	α STEP	α STEP AZ Series	MOTOR
418	<u>FG12D</u>	α STEP	α STEP AZ Series	MOTOR
419	<u>FG14D</u>	α STEP	α STEP AZ Series	MOTOR
420	<u>FG8D</u>	α STEP	α STEP AZ Series	MOTOR
421	<u>FG9D</u>	α STEP	α STEP AZ Series	MOTOR
422	<u>FL12</u>	α STEP	α STEP AZ Series	MOTOR
423	<u>FL8</u>	α STEP	α STEP AZ Series	MOTOR

424	<u>FL9</u>	αSTEP	αSTEP AZ Series	MOTOR
425	<u>PCA2B</u>	αSTEP	αSTEP AZ Series	MOTOR
426	<u>MF930-DC</u>	αSTEP	αSTEP AZ Series	MOTOR
427	<u>MB1040-D</u>	αSTEP	αSTEP AZ Series	MOTOR
428	<u>MB1255-D</u>	αSTEP	αSTEP AZ Series	MOTOR
429	<u>MB1665-D</u>	αSTEP	αSTEP AZ Series	MOTOR
430	<u>MB840-D</u>	αSTEP	αSTEP AZ Series	MOTOR